



# Important!

Maintenance valve must be installed to keep enough back-pressure on the pump discharge to stay on the performance curve and within the motor amp rating.

Running a centrifugal pump without any back-pressure can cause cavitation, low pressure, high vacuum, flow issues, amp over-draw and other problems.

Please visit [www.camacindustries.com](http://www.camacindustries.com) for detailed installation and operating instructions if needed or call us at 973-300-5575.

The WorkHorse Of The Industry™  
**CLYDESDALE**  
Pumps and Filters 

18 Gail Court, Sparta, NJ 07871 • 973-300-5575 • FAX 973-300-5576 [www.camacindustries.com](http://www.camacindustries.com)

THE LEADER IN CUSTOMER SERVICE **camac** INDUSTRIES